












设备编号															
主 接 线 方 案	单 线 图	TMY-3*(60*6)						TMY-3×(60×6)+1×(40×4)							
															
用 途		高压进线		高压出线		变压器室		低压总柜		低压出线		电容柜			
主 电 路 电 器 元 件	隔离开关			FLN36-12D/T125-25	1			HD13BX-1000/31	1		HD13BX-1000/31	1	HD13BX-400/31	1	
	熔断器			XRNT-12 50A	3										
	带电显示器	DXN-10T	1	DXN-10T	1										
	避雷器	HY5WS-17/50	3	HY5WS-17/50	3								HY1.5W-0.28/1.3	3	
	变压器					S13-500/10/0.4 Dyn11, Ud%=4.0	1								
	断路器							W型-1000/3 1000A	1		M型-630A/630A M型-400A/400A	2 2	DZ47-D63/3 43A	8	
	接触器												CJ19-43A	8	
	电力电容器												BSMJ0.45-20-3	8	
	电压互感器										BH-0.66-600/5 BH-0.66-400/5	6 6	BHO.66-400/5	3	
	电流互感器							BH0.66-1000/5 0.5	4						
	电流表							42L6-1000/5	3		600/5A、400/5	6+6	42L6-A 400/5	3	
	电压表							42L6 0-450V	1						
	转换开关							LW5D-16HY3/3	1						
	指示灯														
	温控仪						WTZK-02	1							
	热继电器												JR36-43A	8	
	电缆故障指示器	FCI-II	3只	FCI-II	3只										
	功补仪												JKL-5CF	1	
用电名称				变压器保护											
柜体尺寸		800*900*2000		800*900*2000				800*800*2000		800*800*2000		800*800*2000			

注： 1、须加装低压智能型免维护无功自动补偿装置，具备自动过零投切、分相补偿无功,箱变应安装门禁系统、除湿设备。

2、箱变内低压出线柜每路出线预留安装计量、集抄采集器、表计及配网检测终端位置并带漏电保护。

500kVA欧式箱变系统图

设备编号														
主 接 线 方 案	单 线 图	TMY-3*(60*6)								TMY-3×(50×5)+1×(40×4)				
														
用 途		高压进线		高压出线		变压器室		低压总柜		低压出线				
主 电 路 电 器 元 件	隔离开关			FLN36-12D/T125-25	1			HD13BX-1000/31	1		HD13BX-1000/31	1		
	熔断器			XRNT-12 40A	3									
	带电显示器	DXN-10T	1	DXN-10T	1									
	避雷器	HY5WS-17/50	3	HY5WS-17/50	3						HY1.5W-0.28/1.3	3		
	变压器					S13-400/10/0.4 Dyn11, Ud%=4.0	1							
	断路器							W型-1000/3 1000A	1	M型-630A/630A M型-400A/400A	2 2	DZ47-D63/3 43A	8	
	接触器										CJ19-43A	8		
	电力电容器										BSMJ0.45-20-3	8		
	电压互感器									BH-0.66-600/5 BH-0.66-400/5	6 6	BH0.66-400/5	3	
	电流互感器							BH0.66-1000/5 0.5	4					
	电流表							42L6-1000/5	3		600/5A、400/5	6+6	42L6-A 400/5	3
	电压表							42L6 0-450V	1					
	转换开关							LW5D-16HY3/3	1					
	指示灯													
	温控仪					WTZK-02	1							
	热继电器											JR36-43A	8	
	电缆故障指示器	FCI-II	3只	FCI-II	3只									
	功补仪											JKL-5CF	1	
用电名称				变压器保护										
柜体尺寸		800*900*2000		800*900*2000				800*800*2000		800*800*2000				

注： 1、须加装低压智能型免维护无功自动补偿装置，具备自动过零投切、分相补偿无功,箱变应安装门禁系统、除湿设备。

2、箱变内低压出线柜每路出线预留安装计量、集抄采集器、表计及配网检测终端位置并带漏电保护。

400kVA欧式箱变系统图